



WIRE SIDE FACING YOU

INSTALL INSTRUCTIONS:

USDM 88-91 CIVIC/CRX CHASSIS

1. Locate the loose wires located by the new cluster connectors, you will see 7 loose wires.
2. Based on the year of your Civic/Crx you will match up the wires to the pinout above.
3. You can choose to tap into the wires or cut and solder, the choice is yours.
4. connect the loose wires as follows:

| YEAR | LOOSE WIRE | PIN OUT | OE COLOR |
|-------|------------|---------|----------|
| 88-89 | ORANGE | A5 | YEL/RED |
| | GREEN | A3 | GRN/BLK |
| | WHITE | A4 | YEL/WHT |
| | LT GREEN | B3 | YEL/GRN |
| | YELLOW | B5 | YEL/RED |
| | TAN | B10 | GRN/ORN |
| | BLUE | B11 | BLUE |

| YEAR | LOOSE WIRE | PIN OUT | OE COLOR |
|-------|------------|---------|-------------|
| 90-91 | ORANGE | A2 | YELLOW/RED |
| | GREEN | A4 | GREEN/BLACK |
| | WHITE | A6 | YELLOW/WHT |
| | LT GREEN | B3 | YELLOW/GRN |
| | YELLOW | B8 | YELLOW/RED |
| | TAN | B9 | GRN/ORNG |
| | BLUE | B12 | BLUE |



Facebook [facebook.com/CJs.Wiring](https://www.facebook.com/CJs.Wiring)
 INSTAGRAM: [c_zapien](https://www.instagram.com/c_zapien)
 Store link : <http://www.cjs-wiring.com>
 email: czapien82@gmail.com